

Delete card

You can delete one or more cards linked to the same card-account using the menu item **Setup/Card-System/Erase card**. Enter the card in the card reader and confirm with **Delete**.

